

Gigaset

Dune

CL540 - CL540A

GIGASET. INSPIRING CONVERSATION.
MADE IN GERMANY

GIGASET HELPLINE: 084503 18190

Pack contents




- 1 one Gigaset Base station
- 2 one power adapter for the base
- 3 one Gigaset handset
- 4 one phone cord
- 5 two batteries
- 6 one battery cover
- 7 one rubber seal for the headset connection
- 8 one user guide plus one quick start guide

If you have purchased a model with multiple handsets, the package should contain two batteries, one battery cover, one belt clip and one charger 9 with a power adapter 10 for each additional handset.



Connecting the base station


- ▶ Insert the phone cable into the connection socket 1 at the rear of the base until it clicks into place and feed under the cable protection.
- ▶ Insert the power cable for the power adapter into the connection socket 2 at the rear of the base and rotate the right-angle plug under the cable protection.
- ▶ Connect the power adapter 3.
- ▶ Connect the phone jack 4.



Please note:

- ▶ The power adapter must **always be connected**, as the phone will not operate without a power supply.
- ▶ Use only the power adapter and phone cord **supplied**. Pin connections on telephone cables can vary.

Connecting the handset charger (if included)



- ▶ Connect the flat plug to the charging cradle 1.
- ▶ Plug the power adapter into the power socket 2.

- If you have to remove the plug from the charger again:
- ▶ Disconnect the power adapter from the mains power supply.
 - ▶ Press the release button 3 and disconnect the plug 4.

Frequently asked questions

- Q: There is no dial tone.**
A: Press call button for 2 seconds (long press) to obtain dial tone. A short press opens the redial list.
- Q: The line is crackling / not clear.**
A: Have you used the new line cable provided? Please do not use an old cable.
- Q: The display is not clear / seems to be broken.**
A: The display is protected by a plastic film, please make sure you have removed the protective film.
- Q: The handset is not registered.**
A: If your handset is not registered, please follow the Registration handset procedure. (see user manual)
- Q: The caller ID is not working.**
A: Have you subscribed to this service (CLIP) from your provider?
- Q: Message indicator flashing and I cannot retrieve my message.**
A: Message indicator will flash to indicate missed calls as well as new messages of text messages. (see user manual)

Please check:

- Have you used the phone cord supplied
- Have you fully inserted the power cable into the base station
- Have you inserted the batteries correctly
- Have you charged the battery for 8.5 hours
- Have you set up the Date/Time

If you have problems setting up or operating this product please call
GIGASET UK HELPLINE 084503 18190
GIGASET IRL HELPLINE 0818 200 033

To download the latest manuals, visit our web-site: <http://www.gigaset.com>



A31008-M2602-L101-1-7643

Issued by
Gigaset Communications GmbH
Frankenstr. 2a
D-46395 Bocholt

© Gigaset Communications GmbH 2014
All rights reserved. Subject to availability.
Rights of modification reserved.
www.gigaset.com

Preparing the handset

The display is protected by a plastic film. Please remove the protective film!

Inserting the rubber seal for the headset plug socket
Open the battery cover and insert the rubber seal into the groove.



Insert battery



- ▶ Insert the batteries with the polarity in the right direction (for correct +/- direction, see diagram).

- ▶ First orientate the battery cover with the side tabs fitting into the slots on the inside of the casing.
- ▶ Then press the cover until it clicks into place.

- If you have to open the battery cover:
- ▶ Grip the side hollows and slide the battery cover diagonally upwards.

Charging the battery

The battery is supplied with a partial charge. Please charge it completely before use.
 ▶ Charge the handset in the base for **8.5 hours**.




Please note


The handset must only be placed in the designated base or charger.

Setting the date and time

Set the date/time so that the correct date and time can be assigned to incoming calls, and so that you can use the alarm.




- ▶ Press the key **Time** below the display screen to open the input field.
(If you have already set the date/time, open the input field via the menu:
☰ ▶ ⚙ ▶ OK ▶ Date/Time ▶ OK)



- The submenu **Date/Time** is shown on the display.
- ▶ The active input position flashes. Enter the day, month and year as an 8-digit number via the keypad, e.g. 15012013 for 14.10.2014.

If you wish to change the input position, press **left** or **right** on the control key.



- ▶ Press the **down** control key to switch to the time input field.
- ▶ Enter the hours and minutes in 4-digit format via the keypad e.g., 0715 for 07:15 am. Change the input position with the control key if necessary.
- ▶ Press the key **Save** below the display screen to save the entry.

Handset registration

Handsets contained in the package have already been registered to the base. If, however, a handset has not been registered (display "Please register handset" or "Place handset in base"), you must register it to the base. If your handset is flashing the text "No Base" then it can be that:

- ◆ Your base station is not switched on, please check if the power supply is connected properly.
- ◆ There is too much distance between the handset and the base.

If the handset has not been pre-registered or you want to register an additional handset to your base station, use the registration procedure below.

- ◆ **Automatically registering the Gigaset CL540 handset to base station:**

- ▶ Place the handset in the base. If automatic registration does not work, the handset will have to be registered manually.

- ◆ **Manually registering the handset:**

- ▶ **On the base:** Press and hold (min. 3 seconds) the Registration/paging key 1.
- ▶ **On the CL540 handset,** press the display key **Register**.
Or:
☰ ▶ ⚙ ▶ OK ▶ ☰ **Registration** ▶ OK ▶ **Register Handset** ▶ OK

Display shows: **Searching for a base in registration mode.** The connection to the base will be established; this may take some time.

- ▶ Enter the system PIN if required (factory setting: 0000) ▶ OK

You can register up to six handsets to your base. You can also register other Gigaset handsets and handsets from other devices with GAP functionality.



Dial Tone

The dial tone will only be heard when pressing the call button for 2 seconds. A short press will open the redial list.


Message lists

Any messages you receive are saved in the message lists. An advisory tone sounds as soon as a **new entry** appears on a list. The Message key also flashes. Icons for message types and the number of new messages are shown on the idle display. New messages available:

- ◆ On the answer machine (only CL540A)/network mailbox
- ◆ In the missed calls list
- ◆ In the missed alarms list

Open the message list by pressing the Message key.

Example



Answer machine

Activating/deactivating the answer machine

- ▶ ☰ ▶ ☰ ▶ OK ▶ ☰ **Activation** (✓ = activated) ▶ **Change**
- ▶ **Activation:** On / Off

If activated:

- ▶ **Mode:**
 - ☰ **Answer & record / Answer only / Alternating**
 - **Answer & record:** The caller can leave a message;
 - **Answer only:** The caller only hears an announcement and cannot leave a message;
 - **Alternating:** If activated, **Record from:** / **Record until:** Enter the length of time in which messages are recorded.

▶ **Save**

Example

